


Names of Parts


Left side view

14



- | | |
|---|---|
| 1 Lens barrier switch (41) | 8 CUSTOM (customizable) button (99) |
| 2 Memory card slot A (38) | 9 INFRARED switch (97) |
| 3 Memory card slot B (38) | 10 Double memory card slot cover |
| 4 (review recording) button (47)/ Assignable button 5 (100) | 11 DISP. (onscreen display) button (96)/BATT. INFO (battery information) button (159) |
| 5 Lens hood (25) | |
| 6 Focus/Zoom ring (56, 61) | |
| 7 CUSTOM (customizable) dial (99) | |

Right side view




15


- | | | | |
|---|---|----|---------------------------------------|
| 1 | Built-in speaker (104) | 5 | XA35 HD/SD-SDI terminal (112) |
| 2 | MIC terminal (84) | 6 | (headphones) terminal (92) |
| 3 | HDMI OUT terminal (111, 112) | 7 | USB terminal (98) |
| 4 | REMOTE terminal | 8 | DC IN terminal (21) |
| | For connecting commercially available remote controllers. | 9 | AV OUT terminal (111, 113) |
| | | 10 | Grip belt (27) |

Names of Parts

Front view




Back view



- | | |
|--|------------------------------------|
| 1 Instant AF sensor (58, 176) | 8 Viewfinder (25) |
| 2 Remote sensor (28) | 9 Dioptic adjustment lever (25) |
| 3 Illumination sensor (154) | 10 Joystick (32)/SET button (32) |
| 4 AF/MF button (56)/
Assignable button 1 (100) | 11 Strap mount (27) |
| 5 PRE REC (pre-recording) button
(95)/
Assignable button 2 (100) | 12 Assignable button 3 (100) |
| 6 OLED touch screen (26, 31) | 13 Assignable button 4 (100) |
| 7 Focus/Zoom ring switch (61) | 14 Battery attachment unit (21) |
| | 15 START/STOP button (41) |
| | 16 FUNC. button (32) |
| | 17 Serial number |

Top view



17


- | | |
|---------------------------------------|---|
| 1 Built-in stereo microphone
(82) | 6 Power switch (30) |
| 2 Handle attachment unit (24) | 7 POWER / CHG (battery charging)
indicator (21) |
| 3 Mode switch (31) | |
| 4 Zoom rocker (61) | |
| 5 ACCESS indicator (41) | |



Names of Parts

Bottom view

18



- 1 Tripod socket (📖 29)
- 2 BATTERY RELEASE switch (📖 22)
- 3 Eye cup (📖 25)